



## Zebra Autosense Procedure

### Autosense Procedure, Configuration Label and Dump Mode:

**Models: Orion (2442, 2443 and 2543), Transport (P-2242), Xport (P-2222), LP/TLP Strata (2684), LP/TLP-2722, 2742, 3742, LP/TLP-2824, LP/TLP 2844 and TLP-3842**

1. Turn off printer and have media loaded (on older Transports, with no ON/OFF switch, remove battery).
2. Hold feed button down, and turn printer back on (on older Transports, re-insert battery) while holding down the feed button.
3. When the light starts flashing, release the feed button.
4. Printer light will turn green and advance a few blanks.
5. After printer stops advancing and prints the [internal information](https://support.zebra.com/cpws/docs/eltron/epl_config.htm) ([https://support.zebra.com/cpws/docs/eltron/epl\\_config.htm](https://support.zebra.com/cpws/docs/eltron/epl_config.htm)), press the feed button one time.
6. You will get another label with the "Out of Dump" message on it.

Printer is now ready for use.